

CENTER[®] 23

AC/DC TRMS CLAMP METER



CENTER TECHNOLOGY CORP.

4F, NO. 415, Jung-Jeng Rd., Shu-Lin Dist., New Taipei City 238, Taiwan
E-Mail: center@centertek.com
http://www.centertek.com

GCA000023-12000

Specifications

GENERAL SPECIFICATION:

Display: 4 digits LCD display with maximum reading 4200.

Symbol and Scale range:

Adjust automatically according range and input signal.

Polarity: When negative signal is applied to the tester, will show.

Over Load: When the signal larger than the maximum will be shown .

Sample Rate: 2 times/sec for digital data.

Low Power Indication:

When the battery is under the proper operation range, will appear on the LCD display.

Power Source: UM-4 or AAA 1.5V battery x 2

Typical Battery Life: (alkaline battery)

30 hours approx.

Auto Power Off:

If there is no key operation for 15 minutes, the meter will power itself off to save battery consumption.

Disable Auto Power Off:

To disable the function, press the " " Hold button and keep it pressed while powering on the meter. The LCD segments will all light up, and the indicator will not be displayed.

Clamp opening size: 23 mm

Dimension / Weight: 149(L)x59(W)x27.5(H)mm / 133g (include battery)

Accessory: Instruction Manual, Carrying Case, Battery 1.5Vx2

Safety Information

- Do not operate the tester if the body of meter look broken.
- Check the main function and make sure it is at the correct position before each measurement.
- Change the battery when the symbol appears to avoid incorrect data.

Environmental Conditions:

- Altitude up to 2000 meters.
- Operating temperature: 0°C ~ 40°C, <80% RH, non-condensing
- Storage temperature: -10°C ~ 60°C, <70% RH, battery removed
- Pollution Degree: 2
- Installation Categories II


Explanation of Symbols:

- Attention! Refer to operation instructions.
- Dangerous voltage may be present at terminals.
- This instrument has double insulation.

Approvals: EN61010 600V CAT III


Symbol Definition & Button Location

1. Name of Parts & Position:



- ① Current sensing clamp
- ② NCV induction area
- ③ Safety protection ring
- ④ Clamp opening handle
- ⑤ Hold/Inrush button
- ⑥ Zero/LPF button
- ⑦ NCV button
- ⑧ AC/DC button
- ⑨ Power / Backlight button
- ⑩ LCD display
- ⑪ Battery compartment cover

2. LCD Display:



Maintenance

WARNING & CAUTION!

- Before opening the battery door, never use the meter if the battery door is open.
- To avoid contamination or static damage, do not touch the circuit board without proper static protection.

REMARK:

If the meter is not going to be used for a long time, take out the battery and do not store the meter in high temperature or high humidity environment.

When taking current measurement, keep the cable at the center of the clamp to get more accurate test result.

Repairs or servicing not covered in this manual should be performed only by qualified person.

CLEANING:

Periodically wipe the case with a dry cloth and detergent.

Do not use abrasives or solvents on this instrument.

Button Instructions

Hold / Inrush Function:

Press " " button to freeze the data shown on the LCD.

Press it again to exit Data-Hold mode.

If you press and hold the button for 2 seconds, to access inrush current mode, the LCD display will show "INRUSH", "----" until the motor starting up and being detected (5A above). The detection will be done only on time and the output reading will be hold.

To exit inrush current mode, press and hold the button for 2 seconds or " " button.

AC / DC Function:

Press to switch between AC and DC current measurement.

Power On/Off /Back-Light Function:

Press " " button to turn on the meter. Press and hold the button for 2 seconds to turn off.

Press " " button to turn on the LCD back-light. This makes it easier to read in dark environment. Press it again to turn off back-light. The back-light will be automatically turned off after 10 seconds to save battery power.

NCV Function:

Press " " button to enter NCV (non-contact voltage detector) function. " " symbol will appear on the display. To exit NCV mode, press " " button.

Zero / LPF Function:

At AC mode, press " " (LPF) button to LPF (Low Pass Filter) function; at DC mode, press " " (Zero) button to Zero function.

Press " " (LPF) button. " " symbol will appear on the display. Press it again, or press " " button to exit the LPF mode.

Note: This meter is built with LPF function at ACA ranges.

Press " " (zero) button to enter the Zero mode, " " symbol will appear on the display and the reading is stored as reference value for subsequent measurement. Press it again, or press " " button to exit the Zero mode.

Note: This meter is built with Zero function at DCA ranges.


Measuring Instructions

(1) ACA measurement:

Press the "" button to access the AC Current measurement mode. The "" symbol will appear on the LCD display. Open the clamp by pressing the jaw-opening handle and insert the cable to be measured into the jaw. Close the clamp and get the reading from the LCD panel.

Note:

In some occasion that the reading is hard to read, push the "" button and read the result later.




(2) DCA measurement:

Press the "" button to access the DC Current measurement mode. The "" symbol will appear on the display. Open the clamp by pressing the jaw-opening handle and insert the cable to be measured into the jaw.


Note:

In some occasion that the reading is hard to read, push the "" button and read the result later.



(3) Inrush Current Mode:

Press and hold the "" button for 2 seconds to access the Inrush current mode. The LCD display will show "INRUSH", "----" until the motor starting up for a 100ms period and being detected (5A above). The detection will be done only on time and the output reading will be hold.



(4) Low Pass Filter:

The Low-Pass Filter is a filter that passes signals with a frequency lower than a certain cutoff frequency and attenuates signals with frequencies higher than the cutoff frequency.

The Low-Pass Filter offers a cut-off frequency of 160Hz (approx.)

(5) Non-Contact Voltage (NCV):

⚠ DANGER!

The LCD and beeper may not be displayed due to installation condition of electrical circuit or equipment. Never touch the circuit under test to avoid possible danger even if the LCD and beeper for NCV is not displayed. Check the functionality of LCD and beeper on a well-known power supply prior to measurement. When the LCD and beeper doesn't indicate, do not make measurement.

NCV indication is affected by external voltage, and how the meter is held or placed.

Press the "" button to access the NCV measurement mode.


Annunciate and "EF" will appear on the display.

When no or less electric field is detected, the LCD shows "EF".

If the detector senses electric field, the strength will be showed on LCD by "—" with beep no digits type. Level 1(weak) is "—" and the level 4(strong) is "----".

The beeper frequency depends on the strength of electric field also.

Place the edge of the jaw labeled "▲ NCV ▲" near the electric field.



Replacing Battery

1. When the battery voltage drops below proper operation range, the symbol "" will appear on the LCD and the battery needs to be replaced.
2. Before replacing the battery, switch the main dial to "OFF".
3. Open the battery door by a screwdriver.
Replace the old batteries with two UM-4 or AAA size batteries.
4. Close the battery door and fasten the screw.

